



To ensure you get the most out of your Corner Star Screens,
we recommend regular cleaning:

- to conserve the decorative appearance of the surface and
- for the exterior application to reduce corrosion strain

Cleaning Guide

If the screens are not cleaned during its service life, or is cleaned only irregularly or improperly, this accelerates the soiling process. Depending on the influencing conditions, this in turn may lead to irreparable surface defects and even to a complete loss of decorative appearance.

- Only clean water, with slight additives of neutral washing agents (pH 7), is to be used with the aid of soft, non-abrasive cloths, rags or industrial cotton
- the removal of greasy, oily or sooty substances can take place with the use of white spirit free of aromatic compounds or isopropyl alcohol (IPA). Residues of adhesives, silicone cartouche or adhesive tapes, etc., can also be removed in this way.
- use no solvents or similar, containing ester, ketones, polyhydric alcohol, aromatics, ethylene glycol or halogenated hydrocarbon.
- use no scratching, abrasive agents.
- use no strong acids or alkaline detergents.
- use no detergents of unknown compositions.
- detergents must not be used at temperatures higher than a maximum of 25°C.
- the surface temperature must not exceed 25°C during cleaning.
- the maximum exposure period of these detergents must not exceed one hour: when necessary, the entire cleaning process can be repeated after at least 24 hours.
- rinsing with clean cold water is to take place immediately after every cleaning process.
- Fine-textured effects: Use fiber-free cloths. Moderate mechanical support may be given to the cleaning operation using a soft, non-surface-damaging brush